


Front Damper


Reassembly

1. Install the damper unit, bump stop, dust cover, damper spring, mounting collar, mounting rubber and spring mounting rubber on the spring compressor.
2. Install the damper mounting base on the damper unit as shown.

**SHOCK ABSORBER
SPRING COMPRESSOR
07GAE-SE00101**



3. Compress the damper spring.
4. Install the mounting rubber, mounting washer and 10 mm self-locking nut.
5. Hold the damper shaft and tighten the 10 mm self-locking nut.




Installation

1. Loosely install the damper on the frame with the aligning tab facing inside.
2. Install the damper fork on the driveshaft and lower arm. Install the damper in the damper fork so the aligning tab is aligned with the slot in the damper fork.
3. Raise the knuckle with a floor jack until the car just lifts off the safety stands.

NOTE: The damper fork bolt should be tightened with the vehicle on the ground.

**10 x 1.25 mm
39 N·m (3.9 kg-m, 28 lb-ft)**



4. Tighten the damper pinch bolt.
5. Secure the damper fork bolt with a new 12 mm self-locking nut.
6. Secure the damper assembly to the frame with the 10 mm mount nuts.
7. Install the brake hose clamps with the two bolts.