




Reassembly

1. Insert the right carburetor's throttle shaft end (forked), between the washers on the left carburetor's throttle shaft end.
2. Install new O-rings on the fuel vapor pipe, then install it.
3. Set the left and right carburetors up.



4. Connect the choke shaft spring.
 5. Install the rear bracket but don't tighten its screws yet.
 6. Install the front bracket, with new gaskets, but don't tighten its screws yet.
- CAUTION:** Make sure the screw length is correct or you may damage the carburetors.
7. Check that the choke and throttle shafts move smoothly without binding.

8. Tighten the screws in the sequence shown.

