



Timing Belt

Positioning Crankshaft Before Installing Timing Belt



NOTE: Install the timing belt with the No. 1 piston at TDC (Top Dead Center) on the compression stroke.



MANUAL TRANSMISSION:



AUTOMATIC TRANSMISSION:



DIRECTION OF ROTATION

With engine installed, turn crank with socket wrench and extension as shown.

