


Idle Control System

Troubleshooting Flow Chart — Air Conditioning Signal





(From page 6-180)

A/C switch ON.


Does A/C operate ?

NO

See Air conditioner inspection (section 15).

YES

Measure voltage between B8 (+) terminal and A18 (-) terminal.



Is voltage below 1 V ?

NO

Repair open in Red/GRN wire between ECU (B8) and A/C switch.

YES

Air conditioning signal is OK.