




- NOTE: 1. WIRE IN EITHER HIGH SPEED OR LOW SPEED. NOT BOTH .
2. FAN CAN BE WIRED IN 2 SPEED. DO NOT USE STAR / DELTA SWITCH.
3. CHECK ROTATION OF UNIT IS AS PER LABEL ON FAN (OR WARRANTY IS VOID).
4. CHANGE ROTATION OF DIRECTION BY INTERCHANGING 2 PHASES

REV.	DESCRIPTION	DATE	BY	<div><div>CFMAIRSYSTEMS A U S T R A L A S I A</div><div>106 FAIRBANK ROAD CLAYTON SOUTH, VICTORIA 3169 ph: +61 3 9551 4878 email: mail@cfmairsystems.com.au web: www.cfmairsystems.com.au</div></div>	MAT'L / FINISH: N/A		MODEL:
A	ISSUED FOR CONSTRUCTION	04.10.2020	CFM		DRAWN: CFM Airsystems		DIAGRAM # 21
					DATE: October 2020		
					CHECKED: M.KOTSIKAS		DESCRIPTION: ELECTRICAL DIAGRAM No.21
					SCALE: NTS		
					SHEET:	A4	
				UNLESS OTHERWISE STATED DIMENSIONS ARE OUTSIDE DIMS, IN MILLIMETRES AND TO TOLERANCES LINEAR: ±1 ANGLE: ±10° (MIN) HOLES: WITHIN 0.5 OF TRUE POSITION			REV A