


NOTE: For the best power on/off pop performance, the amplifier should be set in the shutdown mode prior to power on/off operation (set SD low to power down the amp).

ToDo: Ferrite (select w/high Z at high F, low Z at low F). Try to block everything >1MHz or so.



C3: Use 1uF to filter high frequency noise, or 10uF if lower frequency noise is present

ISSUE	ADAFRUIT INDUSTRIES		© 2014
DRAWN KTOWN	TITLE		REV A
CHECKED >CHECKED	DATE 6/10/2016 4:23:59 PM	DRG NO >DRGNO	
DATE >DATE	FILE: PAM8302		PAGE: 1/1