


ESP32-DevKitC V4 w/ WROOM



* Require to burn the flash voltage eFuses for avoiding conflict between D2 & MTDI strapping
 **It is important to keep the sd card jumper wire very short (<= 2 inch)
 and plug them directly to the ESP32 pin (not via breadboard).
 **It's critical for the 2 GND on the PMOD to be plug directly to the ESP32 GND pin via short wire!!

Sheet: /
 File: BlueRetro.sch

Title: BlueRetro DIY

Size: USLetter Date: 2020-08-22
 KiCad E.D.A. kicad (5.1.6)-1

Rev: v1.1
 Id: 1/7