

1. Connect the followed 3 EVB into one total kit.

Note: R2 connect by 0 ohm resistor whih is connect P10.5 to proximity sensor in CSK adaptor. But this sensor's SNR<5 is not good and easy to false trigger. So suggest to solidering a wire in R1(Near A3, which is connect to P10.4) for proximity sensor .

