


V5 Premium Kit

diy electronics

Prusa i3 Build Guide



Hi! Congratulations on your purchase of the DIYElectronics.co.za Prusa I3 kit, the best South African 3D Printer Kit! Hopefully this should serve as complete guide to get your printer setup and printing!


This guide will start with a step by step mechanical assembly, followed by electronic wiring and calibration.

Please take note, before continuing with this this guide!


Due to the nature of Rapid Prototype 3D printed parts, cleaning-up, drilling, filing, cutting of the plastic parts may be necessary. This is important. If you want your build to go smoothly you **MUST** read all the *Notes and *Tips along the way. Following this guide will save you time and hassle.
























Contents

[1] Y-Axis	3
[1.1] Y Carriage – Sub-assembly:	5
[1.2] Y-Bed Undercarriage Sub-assembly	6
[1.3] Y-Axis assembly	7
[1.4] Y-Belt Idler Pulley Sub-assembly	9
[1.5] Y-motor mount Sub-assembly	10
[1.6] Y Motor Sub-assembly	11
[1.7] Y-Axis timing belt	12
[1.8] Outer end plates	14
[2] X-Axis	18
[2.1] X-Axis Tensioner Sub-assembly	23
[3] Z-Axis	25
[4] XZ-axis Mate	27
[5] YZ – axis Mate	31
[6] Electronics and Extruder Assembly	34
[7] Endstops	37



[1] Y-Axis



Front gasket	1		y-bed carriage	1		624f flanged bearing	2	
Rear gasket	1		y-axis motor mount	1		LM8UU linear bearing	4	
M10x480 threaded rod	2		Bearing holder	8		Nema 17 stepper motor	1	
M8x475 smooth linear rod	2		y-belt tensioner	1		M10 Nut	12	
front outer plate	1		y-belt holder	1		M10 Washer	8	
Front inner plate	1		IEC mains and switch	1		M3 machine screws, washers, nuts		
Back inner plate	1		USB extender	1		M4 machine screws, washers, nuts		
Back outer plate	1		GT2 20tooth pulley	1				

[1.1] Y Carriage – Sub-assembly:

Parts needed:

- 1x aluminium carriage
- 2x M8x 475mm smooth stainless steel rod
- 4x LM8UU linear bearings
- 8x printed bearing holders
- 1x printed y-belt holder
- 2x M3x 10mm ch screws
- 8x M3x 25mm ch screws
- 10x M3 washers



Slide two LM8UU linear bearings onto each smooth 475 mm rod.

Fix the printed Y-belt to the carriage with the use of two M3x 10 machine screws. Do not worry about the orientation of the Y-belt, it does not make a difference.

Line the bearings, rods, and printed bearing holders with the holes in the Y-carriage as shown in the top diagram.

Fasten it all down with eight M3x25 screws (don't forget the washers)

TIP* Make sure the linear rods slide smoothly within the bearings. Overtightening the bearing holders will restrict movement.





[1.2] Y-Bed Undercarriage Sub-assembly

Parts needed:

- 2x M10x480 threaded rod
- 8x M10 nuts
- 8x M10 washers

Thread M10 nuts and washers onto the two M10 threaded rods as seen in the image above.

Make sure that the distance between the outer washer on one side and the nearest inner washer is **155 mm**. This is important for frame alignment.



[1.3] Y-Axis assembly

Parts needed:

- Y Carriage Sub-assembly
- Y Bed Undercarriage Sub-assembly
- Inner front plate
- Inner back plate
- Front printed gasket
- Back printed gasket
- 4x M10 nuts




Assemble the Y-Axis by sliding the plates and gaskets onto the ends of the smooth and threaded rods. The M8 smooth rods should fit snugly into the printed gasket holes.

There should be exactly enough threaded rod protruding from the printed gaskets to fit M10 nuts onto.

Tighten these four M10 nuts with a size 17 spanner.

NOTE: Make sure that you tighten the 4 M10 nuts on a flat surface to ensure a flat Y-Axis assembly.





[1.4] Y-Belt Idler Pulley Sub-assembly


Parts needed:

- 1x printed Y-belt idler (Bearing holder)
- 2x 624 flanged bearings
- 1x M4x 25 machine screw
- 2x M4 washers
- 1x M4 nyloc nut
- 2x M3x 20 machine screws
- 2x M3 washers
- 2x M3 nuts

First fasten the printed Y-Belt idler bracket to the front inner end plate. Use M3x20 machine screws and fasten into M3 nuts which are to be held captive in the printed bracket.

Feed an M4x25 screw through the bracket and TWO 624 flanged bearings butted up against each other. Don't forget about the washers on either side.

Tighten with an M4 nyloc nut. Do not overtighten to allow your bearing to rotate smoothly.



[1.5] Y-motor mount Sub-assembly

Parts needed:

- 1x motor mount
- 4x M4x10 machine screws
- 8x M4 washers
- 4x M4 nuts

Fix the Y-motor mount to the rear inner end plate using 4x M4x10 screws, washers, and nuts as shown in the image. Make sure that the mount is straight and parallel to the top of the end plate.

NOTE* The distance from the edge of the motor mount to the edge of the end plate needs to be **40mm**.



[1.6] Y Motor Sub-assembly



Parts needed:

- 1x Nema 17 stepper motor
- 1x GT2 20t pulley (with 2 M3 grub screws)
- 4x M3x8 machine screws
- 4x M3 washers
- 1x Allen key

Fix the Y axis Nema 17 stepper motor to the motor mount using four M3x10 machine screws with washers as seen in the picture above. Tighten well, but not enough to strip the thread of the stepper motor.

TIP* Try to orientate your cables so that they come out the bottom of the motor, this will help you in the long run with uniformity of your printer.

Then slide the GT 2 pulley onto the stepper motor shaft. Position the pulley so that the centre of the teeth line up with the centre of the idler bearing on the other side of the axis (see the next section)




[1.7] Y-Axis timing belt









Parts needed:

- 1x Timing belt
- 4x Cable ties

Make sure that the centre of the GT2 pulley, centre of the Y-Belt holder, and the centre of the Y-belt idler bearing are all in line with each other. If they are not, you will need to loosen the pulley grub screws and position the pulley (possibly flip it around). If this still doesn't work you will need to loosen the Y-motor mount M4 screws and reposition the mount.

Following this, flip the entire Y-axis around and attach the timing belt.







[1.8] Outer end plates

****NOTE**** The cutout for the IEC connector is no longer present on the rear outer plate. The IEC connector now is included in the PSU kit



Parts needed:

- 1x rear outer end plate
- 1x USB male to USB female adapter
- 2x M3x10 machine screws
- 2x M3 washers
- 5x M3x20 machine screws
- 10x M3 washers
- 5x M3 nuts

Fix the female end of the USB adapter to the rear outer end plate as seen in the images.



Next up is fixing the outer end plates to the front and rear gaskets. Do this by inserting three M3x20 screws with washers through the read outer end plate – through the gasket and rear inner end plate. Place washers on the protruding ends of the screws and tighten with M3 nuts.






















Well done! Your printer's Y-Axis assembly is now complete!



[2] X-Axis



Parts needed:

420mm smooth linear rods (x-axis)	2x		LM8UU linear bearings	7x	
320mm smooth linear rods (z-axis)	2x		Nema 17 stepper motor	1x	
Printed x-end	1x		GT2 pulley (with grub screws)	1x	
Printed x-end motor	1x		M3x10mm machine screw	3x	
Printed x-axis carriage	1x		M4x25 machine screw	1x	
Y-axis tensioner	1x		M4x20 machine screw	2x	
F624 idler bearing	2x		M4 washer	3x	
M4 Nyloc nut	1x		M4 nut	2x	

STEP 1


- Insert two M8x420 linear rods into the printed x-end motor bracket

STEP 2

- Slide two LM8UU linear bearings onto the bottom rod and one on the top
- Snap the printed x-axis carriage onto the bearings.
- Make sure that the bearings seat perfectly in their mounting cavities to ensure smooth axes movement.


STEP 3

- Press fit the other printed x-end part onto the two linear rods.
- The distance between the two inner faces of the x-end parts (or the length of exposed linear rod) needs to be **347 mm**.




STEP 4

- Slide two LM8UU linear bearings onto each M8x320mm z-axis linear rods
- Press fit the bearings (with rods inserted) into their cavity slots. It is VERY important that the bearings seat perfectly into their slots.



- Check that the x-axis runs smoothly up and down the bearings. If there is excess friction this would indicate improper seating or alignment of the bearings.


NOTE: At this point you need to drill out the 10mm and 3mm holes in each x-end. This is to make your life easier later.



STEP 5


- Slide the 20tooth GT2 pulley onto the shaft of the Nema 17.
- Tighten the two grub screws with a suitable Allen key – thereby fixing the pulley to the motor shaft.

TIP* Try to orientate your cables so that they come out the bottom of the motor, this will help you in the long run with uniformity of your printer.



STEP 6


- Fix the Nema 17 stepper motor to the printed x-end bracket using three M3x10 machine screws.
- Make sure that the center of the pulley's teeth are aligned with the centre of the slot of the printed x-end



[2.1] X-Axis Tensioner Sub-assembly

STEP 7


- Fix the two 624f bearings to the printed x-axis tensioner with an M4x25 machine screw, two M4 washers, and an M4 nyloc nut.



STEP 8

- Slide an M4 nut into the rear captive slot.
- Screw an M4x20 machine screw into the nut.


NOTE: Do not overtighten the screw which houses the two bearings. The bearings should be able to rotate freely on the screw's axis



STEP 9

- Slide the x-axis tensioner Sub-assembly through the printed right side x-end.


NOTE** This can sometimes be a tight fit. You don't want to break the x-end so sanding or filing of the sides of the tensioner may be required.



STEP 10







- Once the tensioner is in, insert an M4x20 machine screw with washer and nut through the tensioner's slot (indicated by the red arrow). This screw acts as a backstop which the M4 screw in the rear of the tensioner sits against.


TIP: Make sure to leave the rear tensioning screw as unscrewed as possible (The image shows the screw fully screwed in and tensioned). You only want to tension it once you have installed the timing belt.



[3] Z-Axis

Parts needed:


Aluminium 6mm frame	1x	
Nema 17 stepper motor with leadscrew	2x	
Printed z-axis bottom left corner	1x	
Printed z-axis bottom right corner	1x	
M3x10 machine screw	12x	
M3 washer	6x	



STEP 1


- Fix the printed z-axis bottom left and right corners to the laser cut aluminium frame. Using 6 M3x10 machine screws.

NOTE: You need to make sure that the machine screws are screwed tight, but do not over tighten and strip the thread of the frame.











STEP 2


- Fix the Nema 17 stepper motors to the z-axis motor mount corners with M3x10 machine screws and washers.
- Route the cables through the holes in the frame at the bottom.



****NOTE**** Remove the two brass leadscrew nuts and keep them aside for the next section.


[4] XZ-axis Mate

Z-axis Sub-assembly	1x	
X-axis Sub-assembly	1x	
Printed z-axis top left corner	1x	
Printed z-axis top right corner	1x	
Leadscrew nut	2x	
M3x10 machine screw	4x	
M3x20 machine screw	4x	
M3 nut	4x	




STEP 1

- Slide the x-axis Sub-assembly down over the z-axis lead screws. You need to make sure that the distance between the x-axis ends are perfect!!
- The z-axis 320mm linear rods need to be press fitted into the bottom z-axis corner mount holes (red arrow). You might need to use a mallet to lightly tap them into place.




STEP 2

- Press fit the **left top z corner** on top of the left 320mm linear rod.
- Fix the left side corner to the aluminium frame with two M3x10 machine screws.



STEP 3


- Press fit the **top right z corner** to the right 320mm linear rod.
- Use a mallet to tap the x-end (indicated by **red** arrows) until the **top right** z-axis corner line up with the aluminium frame holes.



STEP 4


- Once you are satisfied that everything lines up and that the linear rods and leadscrews are ALL parallel with NO bowing – Use two M3x10 machine screws to fix the **top right side** z-corner to the frame.

NOTE: The entire x-axis needs to be able to traverse up and down the z-axis linear rods smoothly without any interference.




STEP 5

- Thread the two leadscrew nuts onto the leadscrews until the flanged section of the nut seats flush up against the top of the x-ends.









STEP 6


- Make sure that the threaded brass nut holes line up with the x-end holes and use four M3x20 machine screws.



You should be able to manually rotate the leadscrews with your hands and traverse the x-axis up and down without too much brass nut friction. If the leadscrews and nuts stick at any point along the z-axis then there is an alignment issue!!!

[5] YZ – axis Mate

ZX axis Sub-assembly	1x	
Y axis Sub-assembly	1x	
Assembled Kit	1x	
Kapton heater pad and thermistor <i>(Attached to above Aluminium Bed)</i>	1x	
Bed springs	4x	
M3x25 countersunk machine screws	4x	



STEP 1


- Slot the Y-axis assembly down into the slots of the aluminium frame. Keep in mind the 155mm clearance distance mentioned in the first section.



STEP 2

- Tighten the M10 nuts with a size 17 spanner. Make sure that the feet of the aluminium frame and the printed gaskets are level!

***TIP** Working on a flat surface will help.



STEP 3



- Install the timing belt similarly to how it was done on the Y-axis. See example picture on the right. Secure ends by x-carriage with cable ties.

***Note** You will need to break away the supports on the x-carriage to insert the belt.




STEP 5

- Using four M3x25 countersunk screws, fix the print bed to the y-carriage. Make sure that there are springs wedged between the bed and the carriage.
- Ensure that the heater pad wires under the aluminium bed face the back of the printer.




[6] Electronics and Extruder Assembly

Arduino Mega	1x	
Ramps 1.4	1x	
12V power supply kit	1x	
Printed standoff	4x	
M4x10 machine screw	2x	
M3x20	4x	
Auto Bed Levelling Kit		
Extruder and hotend Sub-assembly		



STEP 1


- You will receive both your Arduino Mega and Ramps 1.4 control board assembled and 'mated' together. Evenly apply force to the edges of both boards to pry the two apart.
- Fix the Arduino mega to the frame using four M3x20 machine screws and standoffs between the frame and the bottom of the Arduino.
- Once it is secure, press the Ramps 1.4 shield back into place (try not bend any pins and make sure that all the pins are inserted fully).



STEP 2

- Secure the 12V power supply to the frame using two M4x10 machine screws.

The Power supply comes with a protective cover attached. This cover also houses the IEC power socket and fused on/off switch!





STEP 3 - *REFER TO CHARLSTRUDER INSTRUCTIONS ON HOW TO ASSEMBLE THE EXTRUDER*

STEP 4 – Mounting Extruder and Auto Bed Level Probe Mount

- Fix the completed extruder and Auto Bed Levelling Probe mount to the x-axis carriage using two M3x35 machine screws, M3 washers, and M3 nuts.




Tip: You might need to remove the hotend from the clamp temporarily if it is in the way and you can't get your screwdriver on either side of the hotend fins.




Your printer should look like this. Nearly there!!

[7] Endstops

Parts needed:

Printed X-Endstop holder	1x	
Printed X-Endstop holder	1x	
End switch	2x	

You will not need this Z-Endstop due to your inductive probe




STEP 1

Time to attach your two end stops, one for each axis as seen in the image. First thing you need to do is insert the end switches into the printed parts. These press fit into place and have wires pre-soldered on. Make sure that you feed the connector and wire through the back of the holder before you press them down into place.


STEP 2

- Snap the x-axis end switch holder onto the two M8 smooth rods.



STEP 3


- Snap the y-axis end switch assembly to the M10 threaded rod. The top 'hook' keeps the mount vertical.



STEP 4

Now it's time to position the two end switch assemblies. The point of this is to ensure the tip of the nozzle 'homes' to the front left corner of the bed.

- First up is the x-axis. Position the X end-switch assembly so that the tip of the nozzle lines up with the left edge of the print bed when the switch makes contact with the x-carriage.



- Next is the y-axis. The Y end switch assembly needs to be positioned so that the tip of the print nozzle lines up with the front edge of the print bed.

The switch actuates up against the edge of the plastic bearing holder.

