



1. Signals route along  
Module side PCB  
(1m max)




2. Signals pass to  
active ganging  
PCB




3. Then to PD Module Connector

Cables exit APA Top




Through  
PD Flange



6. To cryostat  
feedthrough

4. Then through  
Cat-6 cables  
Inside lower and  
Upper APA



5. Cat 6 cable routed  
In cable trays

