


## LGF\_IntToString

### Short description

This block converts a variable of the system data type "DInt" into a variable of the data type "String".

### Block



### Input parameters

Parameters	Data type	Description
value	DINT	Integer value

### Output parameters

Parameters	Data type	Description
Ret_Val	STRING	Converted value as string. Example: '+16927'

### Further information on libraries in TIA Portal:

- Topic page libraries  
<https://support.industry.siemens.com/cs/ww/en/view/109738702>
- Guideline on Library Handling  
<https://support.industry.siemens.com/cs/ww/en/view/109747503>
- Programming Guideline for S7-1200/1500 in chapter "Libraries"  
<https://support.industry.siemens.com/cs/ww/en/view/81318674>
- Programming Styleguide  
<https://support.industry.siemens.com/cs/ww/en/view/81318674>