

Electrical AC BOM (Phase 1)

As-of date: 2026-02-13

Purpose: lock the compact AC parts list for the current truck-camper topology using:

- 2x small DIN enclosures (input and output)
- 1x dedicated shore input breaker
- 2x AC-out branch breakers

Related docs:

- docs/ELECTRICAL_overview_diagram.md
- bom/bom_estimated_items.csv

Locked Topology

Input enclosure (shore to inverter)

- Path: shore inlet -> AC input breaker -> MultiPlus AC-in (L)
- Neutral path: shore N -> insulated neutral terminal/splice -> MultiPlus AC-in (N)
- Ground path: shore PE -> ground bar/stud -> MultiPlus PE + chassis bond

Output enclosure (inverter to outlets)

- Path: MultiPlus AC-out-1 (L) -> hot feed splitter -> 2x branch breakers
- Branch A (driver): breaker output to first GFCI/outlet chain
- Branch B (passenger): breaker output to first GFCI/outlet chain
- Neutral path: AC-out-1 N -> output neutral bar -> both branch neutrals
- Ground path: AC-out-1 PE -> output ground bar -> both branch grounds

Buy List (AC-Specific)

1. 2x DIN enclosures, 2-way each, with included rail and cable-entry hardware.
2. 3x DIN-mount breakers, UL 489 , 1-pole , 120VAC :
 - 1x 20A for shore input protection
 - 1x 20A for driver-side branch
 - 1x 15A for passenger-side branch
3. 1x hot distribution block (1-in / 2-out) for output enclosure feed split.
4. 2x insulated neutral bars or terminal blocks:
 - 1x for input enclosure
 - 1x for output enclosure
5. 2x ground bars (or equivalent grounded termination points):
 - 1x for input enclosure
 - 1x for output enclosure
6. Cable glands / strain reliefs sized for planned AC cable runs (10/3 shore feed, 12 AWG branch).
7. Terminal consumables:
 - ferrules/ring terminals sized to actual wire and terminal type
 - adhesive heat shrink
8. Enclosure completion hardware:
 - DIN end-stops
 - blank fillers
 - circuit labels

Receptacle Plan (Current)

- 4 total receptacle locations (2 galley/driver zone, 2 office/passenger zone)
- Preferred protection strategy:
- 2x GFCI receptacles at first outlet in each branch

- downstream standard receptacles on GFCI load side where applicable

Critical Wiring Constraints

1. Do not share a common hot bus between AC-in and AC-out circuits.
2. Keep AC-in neutral and AC-out neutral termination paths isolated.
3. Land only conductors allowed by each breaker terminal listing (no unlisted double-lugging).
4. Maintain continuous equipment ground path and chassis bond.

Procurement Notes

- Enclosure listings alone do not qualify breaker protection suitability.
- Breakers should be confirmed as UL 489 listed for branch/feeder protection use.
- Final SKU lock should be recorded back into bom/bom_estimated_items.csv rows:
- 13 , 109 , 110 , 111 , 112 , 113 , 114 , 115 , 116 .