




## VSVR UNIT TEST INSTRUCTIONS



2. Power up unit, watch power switch, push button for LED lights and the battery LED flashes a few times when starting up- when the screen boots continuously hit delete on keyboard






3. Check the date and time. **(In military time)**






## VSVR UNIT TEST INSTRUCTIONS

**4.** Go to avago- make sure you see 10 drives three times.





## VSVR UNIT TEST INSTRUCTIONS



**9.** Exit out of the above screen -> Right click on screen -> dtechlabs -> CPU testing -> CPU test



## VSVR UNIT TEST INSTRUCTIONS

