


Users/davidflynn/Projects/Rocket-Parts/Parachute.scad



Scale is to calibrate actual printed dimension. Check both X and Y. Measure between tick 0 and last tick

