



0 10,000 20,000 FEET



EXPLANATION



Irrigated model cell



Active model cell

8,4

Segment number and reach number

— 1000 —

Contour—Shows altitude of land surface.

Contour interval is 20 feet



Basin-fill boundary