


increase_speed()

 dexterindustries.com/GoPiGo/programming__trashed/python-programming-for-the-raspberry-pi-gopigo__trashed/increase_speed/

Stop the Increase the speed of the GoPiGo

The speed of the GoPiGo can be between 0-255. The default speed is 200. You can use `increase_speed()` to increase the speed of the GoPiGo by 10

Syntax

```
increase_speed()
```

Parameter:

None

Return:

1 on success

-1 on error

Example

```
from gopigo import *  
increase_speed()
```