

right_rot()

 dexterindustries.com/GoPiGo/programming__trashed/python-programming-for-the-raspberry-pi-gopigo__trashed/right_rot/

Rotate GoPiGo Right

The right motor starts rotating back and the left motor starts rotating forward. This makes the GoPiGo rotate towards right at the same spot.

Syntax

```
right_rot()
```

Parameter:

None

Return:

1 on success

-1 on error

Example

```
from gopigo import *  
right_rot()
```