

BLOWER MOTOR [MANUAL AIR CONDITIONER]

id0740a2320800

Purpose


- The blower motor sends airflow into the cabin.

Function

- The blower motor rotates the blower fan to create airflow and sends out the airflow in the blower unit and A/C unit.

Construction


- The blower motor is installed to the blower unit.
- The blower motor consists of the blower fan and motor.
- A sirocco fan has been adopted for the blower fan.



ac5wzn00000750

Operation

1. The front body control module (FBCM) turns on the blower relay based on the blower ON signal sent from the climate control unit.
2. When the blower relay turns on, the blower motor fan rotates.
3. The rotation speed of the blower fan is determined by the resistance in the resistor. If the resistance is low, the rotation speed increases, if the resistance is high, the speed decreases.



ac5wzn00000751

Fail-safe

- Function not equipped.