



ac5wzw00005118

- |   |   |
|---|---|
| 1 | Ignition coil/ion sensor<br>(See IGNITION COIL/ION SENSOR REMOVAL/<br>INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G<br>2.5].)<br>(See IGNITION COIL INSPECTION [SKYACTIV-G<br>2.0, SKYACTIV-G 2.5].) |
|---|---|

- |   |  |
|---|--|
| 2 | Spark plug<br>(See SPARK PLUG REMOVAL/INSTALLATION<br>[SKYACTIV-G 2.0, SKYACTIV-G 2.5].)<br>(See SPARK PLUG INSPECTION [SKYACTIV-G<br>2.0, SKYACTIV-G 2.5].) |
|---|--|