


## END COVER INSPECTION

id051700663400

### Radial Needle Bearing Inspection

1. Rotate the radial needle bearing shown in the figure by hand and verify that there is no malfunction in the radial needle bearing (rotation sticking).
  - If there is a malfunction, replace the end cover with a new one.



azzjw00001340