

## UPPER COWL SIDE REINFORCEMENT INSTALLATION [PANEL REPLACEMENT]

id098008828600


### Symbol Mark

SYMBOL MARK	MEANING
■	PLUG WELDING (ARC WELDING)

ac5wzb00000211

### Installation Procedure

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for the plug welding before installing the new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.
4. Plug weld the 21 locations shown in the figure, then install the upper cowl side reinforcement.



ac5wzb00000327