


## FRONT DOOR TRIM DISASSEMBLY/ASSEMBLY

id091700804200

### Driver-side

1. Disassemble in the order shown in the figure.




ac5wzw00001675

1	Switch panel cover
2	Power window main switch (See Power Window Main Switch And Power Window Subswitch Removal Note.)
3	Fastener
4	Front door trim

2. Assemble in the reverse order of disassembly.

### Passenger-side

1. Disassemble in the order shown in the figure.



ac5wzw00001676


1	Switch panel cover
2	Power window main switch (See Power Window Main Switch And Power Window Subswitch Removal Note.)
3	Fastener
4	Front door trim

2. Assemble in the reverse order of disassembly.


#### **Power Window Main Switch And Power Window Subswitch Removal Note**

1. Pull the edge of power window main switch cover in the direction of arrow (1) and detach the tab.

## Driver-side



## Passenger-side



ac5wzw00001678

2. Remove the power window main switch in the direction of arrow (2) shown in the figure.