

LOWER COWL SIDE REINFORCEMENT INSTALLATION [PANEL REPLACEMENT]

id098008828800


Symbol Mark

SYMBOL MARK	MEANING
●	SPOT WELDING
■	PLUG WELDING (ARC WELDING)

ac5wzb00000212

Installation Procedure

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for the plug welding before installing the new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.
4. Spot weld the 19 locations indicated by (A) shown in the figure.
5. Plug weld the 26 locations indicated by (B) shown in the figure, then install the lower cowl side reinforcement.



ac5wzb00000266