


## FRONT ACCESSORY SOCKET INSPECTION

id092100900800

1. Remove the front accessory socket. (See FRONT ACCESSORY SOCKET REMOVAL/INSTALLATION.)
2. Connect the tester probe to the position shown in the figure and verify that there is continuity.
  - If it cannot be verified, replace the front accessory socket. (See FRONT ACCESSORY SOCKET REMOVAL/INSTALLATION.)



ac5wzw00001122