


HEADLIGHT CLEANER COVER REMOVAL/INSTALLATION

id091900814100

Caution

- Before removing the headlight cleaner cover, affix protective tape to the positions shown in the figure. Otherwise, it could damage the front bumper.




ac5uuw00000830

Caution


- Forcefully pulling the headlight cleaner cover could damage it. Be careful when pulling the headlight cleaner cover.

1. Pull out the headlight cleaner cover in the direction of the arrow (1) shown in the figure.



ac5uuw00000831

2. While the headlight cleaner cover is pulled out, disengage tabs in the direction of the arrow (2) and remove them.



ac5uuw00000832

3. Install in the reverse order of removal.