

---

## BLIND SPOT MONITORING (BSM) OFF SWITCH REMOVAL/INSTALLATION

id092200014100

### Note

- The BSM OFF switch is integrated with the cluster switch.
- For the cluster switch removal/installation, refer to the switch panel removal/installation because the cluster switch is installed to the switch panel. (See SWITCH PANEL REMOVAL/INSTALLATION.)