

WASHER NOZZLE


id091900202000

Purpose

- The washer nozzle sprays the washer fluid sent from the washer motor to the optimum positions on the windshield.

Construction

- A ball-shaped spray orifice is set inside the washer nozzle which can be adjusted up or down.




ac5wzn00000542


- The washer nozzle is moved up and down using the adjustment holes.

ADJUSTMENT
HOLE (UPSIDE)


ADJUSTMENT
HOLE (DOWNSIDE)



UPWARD ADJUSTMENT



DOWNWARD ADJUSTMENT



ac5wzn00000594

Fail-safe

- Function not equipped.