

## FLOOR SIDE PANEL INSTALLATION [PANEL REPLACEMENT]

id098008618800


### Symbol Mark

SYMBOL MARK	MEANING
●	SPOT WELDING
■	PLUG WELDING (ARC WELDING)

ac5wzb00000224

### Installation Procedure

1. When installing new parts, measure and adjust the body as necessary to conform with standard dimensions.
2. Drill holes for the plug welding before installing the new parts.
3. After temporarily installing new parts, make sure the related parts fit properly.
4. Spot weld the 7 locations indicated by (A) shown in the figure.
5. Spot weld the 5 locations indicated by (B) shown in the figure, then install the floor side panel No.2.



ac5wzb00000263

6. Plug weld the 35 locations indicated by (C) shown in the figure, then install the floor side panel No.1.

FLOOR SIDE PANEL No.1

