


INSTANT MOBILITY SYSTEM

id021200629800

- Instant mobility system enables temporary repair of a puncture without tire removal.
- The instant mobility system is located in trunk compartment and includes the following:



ac5wzn00000901

- Repair agent
- Repair agent filler hose
- Air compressor
- Tire valve core
- Tire valve core tool
- Instruction manual
- Speed limit label
- Filled tire indication label

- The accessory socket (12 V DC) is used as an input power source for the air compressor and the compressor plug includes a fuse.

Note

- The expiration date of the repair agent is printed on the repair agent bottle. Do not use the repair agent if the expiration date has expired.

-
- Dispose of the repair agent according to local waste disposal law.