

CLUTCH FLUID LEAKAGE INSPECTION [C66M-R, C66MX-R]


id0510mc158400

Caution

- Do not allow clutch fluid to get on a painted surface. Clutch fluid contains properties which can dissolve the paint. If clutch fluid gets on a painted surface, wash it off with water immediately and wipe the area off completely.

1. Verify reserve tank cap is on tight.
2. Pump the clutch pedal a few times.
3. Inspect for the clutch fluid leakage at the points indicated in the figure.

L.H.D.




ac5wzw00002830

R.H.D.

Note

- If there is clutch fluid leakage from the piston in the clutch release cylinder, there is clutch fluid in the boot of clutch release cylinder.
- If there is clutch fluid leakage, repair or replace the malfunctioning location.



ac5wzw00002831