
EXCESSIVE CREEP [GW6A-EL, GW6AX-EL]

id050320100700

TROUBLESHOOTING ITEM	Excessive creep
DESCRIPTION	• Vehicle accelerates in D and R position when accelerator pedal is not depressed.
POSSIBLE CAUSE	1. Not within idle speed specification

Diagnostic procedure

STEP	INSPECTION		ACTION
1	INSPECT ENGINE CONTROL SYSTEM FOR MALFUNCTION • Perform the symptom troubleshooting "NO.14 FAST IDLE/RUNS ON". (See NO.14 FAST IDLE/RUNS ON [SKYACTIV-D 2.2].) • Is there any malfunction?	Yes	Repair or replace any malfunctioning parts according to the inspection result.
		No	Symptom troubleshooting is completed.