



- Easiest way for assembly:
- 1.) Mount the ProMicro in its position (with hot glue, only on unused pin header)
 - 2.) Solder enamelled wire on ProMicro (just one side, take care of sufficient length)
 - 3.) Mount the JackPlugs, fix with hot glue
 - 4.) Solder GND connection
 - 5.) Solder remaining signals
 - 6.) Stabilize the USB plug with hot glue (attach a cable, otherwise you may have glue IN the plug).

www.asterics-foundation.org

AsTeRICS Foundation

Sheet: /

File: FABL_schematic.sch

Title: FABL schematic for 8 jack plugs

Size: A4 Date: 2019-09-27

KiCad E.D.A. kicad 5.1.4+dfsg1-1

Rev:

Id: 1/1