

- A1 Injector1
- A3 Injector2
- A5 Injector3
- A6 Purge cutoff
- A7 Injector4
- A8 UTEC solenoi
- A10 FPR cutoff
- A11 EAUC valve
- A12 MAIN RLY GND
- A13 SIGNAL GND
- A16 CHASSIS GND

- B1 Stby power in
- B3 A/C clutch relau
- B5 Oil pres su
- B6 Check-Eng light
- B8 A/C switch in
- B10 Crank sens1-2
- B11 demist SW in
- B12 Crank sens2-2
- B13 Starter in?
- B14 Alternator?
- B15 Ignitor out1-2
- B16 USS in
- B17 Ignitor out2-2
- B19 Knock sens in
- B20 Timing adj con

- C1 CYL sens1-2
- C2 CYL sens2-2
- C3 TDC sens1-2
- C4 TDC sens2-2
- C5 IAT sens
- C6 ECT sens
- C7 TPS wiper
- C8 O2 sens B
- C10 Brake SW
- C11 MAP sens1-3
- C12 Sens GND?
- C13 TPS +ve
- C14 MAP sen3-3
- C15 MAP sen2-3
- C16 O2 sens A

