











P10
Power Input

Wire to
XT60 Connector, and
power from 4S-6S LiPo



Note: The VUSB trace must be cut
on the back of the Teensy
board before powering the
Teensy from USB.

