



# ANALOG FUNCTION GENERATOR USER MANUAL



- 1 - frequency range changer high to low (left to right)
- 2 - wave selector (bottom to up)
  - triangular
  - square
  - sine
  - saw-tooth
- 3 - main frequency adjustment knob
- 4 - fine frequency adjustment knob
- 5 - offset controlling knob (triangular)  
duty cycle changing knob (square)
- 6 - frequency range changer(sine wave)
- 7 - sine wave amplifying knob (sine wave)
- 8 - amplifier
- 9 - power on off switch
- 10 - positive output terminal
- 11 - negative output terminal

## Rated Power Input

- 230v
- 50Hz

## Output Range

- maximum voltage 10v
- frequency range 20Hz - 20000Hz