



- 1502->1509:
1. Use 3.3V low dropout regulator
 2. Disconnect TOUT1 to U11
 3. R2 is not installed
 4. Disconnect LCD_REB to nRESET, and Connect LCD_REB to U11.2
 5. Modify U11 firmware for LQ043T1DH04 LCD Module

| | | | |
|--------------|-----------------------------|-------|--------|
| Title | | | |
| LCD-P43 1509 | | | |
| Size | Document Number | | Rev |
| A3 | <Doc> | | |
| Date: | Wednesday, October 14, 2015 | Sheet | 1 of 1 |