

LED ON FOR EVENT detect

SPARK FUN AS3935


PIN MAP

Teensy 4.0

D12 =
 D11 = TKT MOSI
 D13 = TKT SCK
 D9 = TKT C/D
 D4 = TKT Reset
 D2 = TKT CS
 D3 =
 D6 =

SPK FUN

MISO
 MOSI
 SCK
 INT
 CS



NOTE: The AS3935 Board should be at least 6" AWAY From 74HC244 and the rest of CKTRY

SW5 Range Select (outdoor - close)

SHD LIGHTNING Detector V2.0 2/24/25