




CONNECTORS




SQUARE-TRIANGLE GENERATOR




SQUARE GENERATOR




TRIANGLE - SINE SHAPER



OUTPUT PRESCALE




OUTPUT SELECT




PANEL MOUNT

POWER



INDICATORS



OUTPUT AMPLITUDE / OFFSET

