

Device Mode

As labeled

Select Track

Press wheel to browse
Presets/Devices

Previous/Next
Device Page

Remote
Controls

Device
Faders

Previous/Next
Device

Browsing Presets

Select Preset to audition

Press wheel to confirm

Use wheel to select Presets

Use wheel to select Category or Creator

Cancel

Confirm