

# Commands for EV3-API

## Initialization:

command	explanation
#include <ev3.h>	including Header
InitEV3();	Initialization of all EV3-Functions
FreeEV3();	Closing of all EV3-Functions

## Display:

command	explanation
bool LcdClean();	Erase Display
LcdPrintf(<Color>,<Text>,...);	Working like printf()

## Help:

parameter	type	explanation	value
<Color>	char	Color of text	1: black text 0: white text with black background
<Text>	char*	Pointer to text	e.g. "Hello EV3"

## Break:

command	explanation
void Wait(<Zeit_ms>);	Break code for a given time

## Help:

parameter	type	explanation	value
<Zeit_ms>	unsigned long	time in ms possible to use the given macros or type directly the value	MS_1...10 :1 10...100 :10 50...500 :50 100...900 :100 SEC_1...10 :1 5...20 :5 30 MIN_1

## Inputs (Sensoren):

### Commands:

command	explanation
int <b>setAllSensorMode</b> (<Mode>, <Mode>, <Mode>, <Mode>);	Allocate of the sensor types of all 4 ports in the correct order (IN_1, IN_2, IN_3, IN4)
int <b>readSensor</b> (<Input>);	Readout of the actual sensor data
int <b>setIRBeaconCH</b> (<Input>, <Channel>);	Set Channel of the Beacon for Readout (default: Ch. 1 )

### Help:

parameter	type	explanation	value
<Input>	int	Input-Ports	IN_1, IN_2, IN_3, IN_4
<Mode>	char	Name und Mode of the connected Sensors	See next table
<Channel>	int	Channel of the Beacon. Needed for: IR_SEEK and IR_REMOTE	BEACON_CH_1, BEACON_CH_2, BEACON_CH_3, BEACON_CH_4

### Sensor type:

Sensor	<Mode>	explanation	return value
<b>No Sensor</b>	NO_SEN	No sensor to the port connected	-1
<b>Touch sensor</b>	TOUCH_PRESS	Return of state (2 states possible)	Not pressed: 0 pressed: 1
<b>Light sensor</b>	COL_REFLECT	Return of the reflected light intensities in %	0 to 100
	COL_AMBIENT	Return of room light intensities in %	0 to 100
	COL_COLOR	Return of color	0: transparent 1: black 2: blue 3: green 4: yellow 5: red 6: white 7: brown
<b>Sonar sensor</b>	US_DIST_MM	Return of distance in mm	0 to 2550
<b>Gyroscope</b>	GYRO_ANG	Return of angle in °	-180 to 180
	GYRO_RATE	Return of gear rate in °/s	-440 to 440
<b>EV3 Infrared</b>	IR_PROX	Return of distance in % (up to 70cm)	0 (Near) to 100 (Far)
	IR_SEEK	Position of the Beacon	-25 to 25
	IR_REMOTE	Controlling EV3 with Beacon	BEACON_OFF BEACON_UP_LEFT BEACON_DOWN_LEFT BEACON_UP_RIGHT BEACON_DOWN_RIGHT BEACON_UP BEACON_DIAG_UP_LEFT



		BEACON_DIAG_UP_RIGHT BEACON_DOWN BEACON_ON BEACON_LEFT BEACON_RIGHT
NXT Infrared	NXT_IR_SEEKER	1 to 9

## Outputs (Motoren):

### Controlling:

command	explanation
void <b>OnFwdReg</b> (<Output>, <Speed>);	Forwards/backwards with given speed
void <b>OnRevReg</b> (<Output>, <Speed>);	
void <b>OnFwdSync</b> (<Output>, <Speed>);	synchronized forwards/backwards with given speed (only working with two motors)
void <b>OnRevSync</b> (<Output>, <Speed>);	
void <b>Off</b> (<Output>);	Switch off motors
void <b>RotateMotor</b> (<Output>, <Speed>, <Angle>);	Rotate with given speed for a defined angle (Code stops till the angle is reached)

### Reading out:

command	explanation
int <b>MotorRotationCount</b> (<Output>);	Rotation angle of the motors in °
void <b>ResetRotationCount</b> (<Output>);	Reset of rotation angle
char <b>MotorPower</b> (<Output>);	Actual motor speed

### Help:

parameter	type	explanation	value
<Output>	int	Output-ports	OUT_A, OUT_B, OUT_C, OUT_D, OUT_AB, OUT_AC, OUT_AD, OUT_BC, OUT_BD, OUT_CD, OUT_ABC, OUT_BCD, OUT_ABCD, OUT_ALL
<Speed>	char	speed	0 to 100
<Angle>	int	angle in °	

## Buttons und LED:

### Functions for LED:

command	explanation
void <b>SetLedPattern(&lt;Pattern&gt;);</b>	Changing color of LED behind buttons
void <b>SetLedWarning (&lt;Value&gt;);</b>	Activate/deaactivate of warning. LED color cannot be changed while warning is set.

### Functions for buttons:

command	explanation
word <b>ButtonWaitForAnyPress(&lt;Zeit&gt;);</b>	Waiting for button press for given time
bool <b>ButtonIsUp(&lt;Button&gt;);</b>	Check if button is pressed or not
bool <b>ButtonIsDown(&lt;Button&gt;);</b>	(1: true, 0: false)
void <b>ButtonWaitForPress(&lt;Button&gt;);</b>	Waiting till a specific button is pressed
void <b>ButtonWaitForPressAndRelease(&lt;Button&gt;);</b>	Waiting till a specific button is pressed and released

### Help:

parameter	type	explanation	value
<b>&lt;Pattern&gt;</b>	byte	Color and modus of LED	LED_BLACK (0) LED_GREEN (1) LED_RED (2) LED_ORANGE (3) LED_GREEN_FLASH (4) LED_RED_FLASH (5) LED_ORANGE_FLASH (6) LED_GREEN_PULSE (7) LED_RED_PULSE (8) LED_ORANGE_PULSE (9)
<b>&lt;Value&gt;</b>	bool	Activate or deactivate	0: deactivate 1: activate
<b>&lt;Zeit&gt;</b>	uint	time in ms	0: for endless waiting
<b>&lt;Button&gt;</b>	byte	Name of button	BTNEXIT, BTNRIGHT, BTNLEFT, BTNCENTER, BTNUP, BTNDOWN