

A16	ABS control module
B161	AC refrigerant pressure sensor
B138	Accelerator pedal position (APP) sensor
G1	Alternator
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
Y81	Camshaft position (CMP) actuator
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
A95	Engine coolant blower motor control module
B24	Engine coolant temperature (ECT) sensor
R96	Engine coolant thermostat
H63	Engine malfunction indicator lamp (MIL)
B86	Engine oil level sensor
S389	Engine oil pressure switch
Y104	Evaporative emission (EVAP) canister purge valve
Y28	Exhaust gas recirculation (EGR) solenoid
Y63	Fuel pressure regulator control solenoid
M12	Fuel pump (FP)
B186	Fuel rail pressure (FRP) sensor
F	Fuse
X28-II	Fuse box/relay plate - engine bay 1
X28-III	Fuse box/relay plate - engine bay 2
X28-I	Fuse box/relay plate - fascia
B72-I	Heated oxygen sensor (HO2S) 1
B72-II	Heated oxygen sensor (HO2S) 2
T1	Ignition coil
15	Ignition switch - ignition ON
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
R9	Intake manifold heater
R9-I	Intake manifold heater 1
R9-II	Intake manifold heater 2
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
K181	Module supply relay
A11-II	Multifunction control module 2
M89	Throttle motor
B169	Throttle motor position sensor
A57	Transmission control module (TCM)
B105	Turbocharger (TC) boost pressure sensor
M174	Turbocharger (TC) engine coolant pump
Y153	Turbocharger (TC) intake divert valve
VAN	Vehicle area network

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.



