


A16	ABS control module
K143	AC compressor clutch relay
B138	Accelerator pedal position (APP) sensor
X93	Airbag spiral cable
G1	Alternator
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
Y183	Camshaft position (CMP) actuator, exhaust
Y182	Camshaft position (CMP) actuator, intake
B132	Camshaft position (CMP) sensor
B132-I	Camshaft position (CMP) sensor 1
B132-II	Camshaft position (CMP) sensor 2
A167	Clutch control module
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
R57	Crankcase breather heater
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
X1-I	Data link connector (DLC) 1
K46	Engine control (EC) relay
A35	Engine control module (ECM)
M6	Engine coolant blower motor
B187	Engine coolant blower motor temperature sensor
B24	Engine coolant temperature (ECT) sensor
R96	Engine coolant thermostat
B86	Engine oil level sensor
S25	Engine oil pressure warning lamp switch
M12	Fuel pump
K20	Fuel pump relay
Y70	Fuel tank vent valve
F	Fuse
X28-II	Fuse box/relay plate, engine bay
X28-I	Fuse box/relay plate, fascia
B72	Heated oxygen sensor (HO2S)
B72-I	Heated oxygen sensor (HO2S) 1
B72-II	Heated oxygen sensor (HO2S) 2
B72-III	Heated oxygen sensor (HO2S) 3
B72-IV	Heated oxygen sensor (HO2S) 4
T1	Ignition coil
K189	Ignition coil relay
15	Ignition switch - ignition ON
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
Y66	Intake air flap control actuator
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
B30	Mass air flow (MAF) sensor
M73	Secondary air injection (AIR) pump

K152	Secondary air injection (AIR) pump relay
S365	Steering wheel multifunction switch
S365-I	Steering wheel multifunction switch 1
A177	Throttle control unit
M89	Throttle motor
B169	Throttle motor position sensor
15	Under front seat, LH
K298	Variable valve lift control module relay
M156	Variable valve lift position motor, inlet
B229	Variable valve lift position sensor, inlet



bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	wbl = light blue	wgn = light green	wbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

