


S341	AC refrigerant triple pressure switch
B138	Accelerator pedal position (APP) sensor
B121	Barometric pressure (BARO) sensor
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
B54	Crankshaft position (CKP) sensor
S101	Cruise control brake pedal switch
X1	Data link connector (DLC)
A35	Engine control module (ECM)
K12-I	Engine coolant blower motor relay 1
K12-II	Engine coolant blower motor relay 2
K12-IV	Engine coolant blower motor relay 4
R93	Engine coolant heater
K242	Engine coolant heater relay
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y28	Exhaust gas recirculation (EGR) solenoid
Y28-I	Exhaust gas recirculation (EGR) solenoid 1
Y28-II	Exhaust gas recirculation (EGR) solenoid 2
B131-I	Exhaust gas temperature sensor 1
B131-II	Exhaust gas temperature sensor 2
B232	Exhaust particulate filter pressure differential sensor
H139	Exhaust particulate filter warning lamp
A242	Fuel additive control module
Y199	Fuel additive injector
M153	Fuel additive pump
S424	Fuel filler cap position switch
Y63	Fuel pressure regulator control solenoid
M12	Fuel pump
B186	Fuel rail pressure (FRP) sensor
B31	Fuel temperature sensor
F	Fuse
X28-II	Fuse box/relay plate, engine bay 1
X28-IV	Fuse box/relay plate, engine bay 2
X28-I	Fuse box/relay plate, fascia 1
X28-III	Fuse box/relay plate, fascia 2
K93	Glow plug timer relay
H25	Glow plug warning lamp
R5	Glow plugs
15	Ignition switch - ignition ON
15	In tailgate, RH
S39	Inertia fuel shut-off (IFS) switch
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
Y84	Intake air valve control valve
B83	Manifold absolute pressure (MAP) sensor
B30	Mass air flow (MAF) sensor

A11	Multifunction control module
Y160	Piston cut-off solenoid
A171	Relay module
P7	Tachometer
Y68	Turbocharger (TC) wastegate regulating valve
B33	Vehicle speed sensor (VSS)
P9	Vehicle speedometer



AD72818

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

