


X88	AC connector
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
Y3	Injector
B25	Intake air temperature (IAT) sensor
Y102	Intake manifold air control solenoid
R9	Intake manifold heater
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
K46	Relay module
P7	Tachometer
B147	Throttle position (TP) sensor
B33	Vehicle speed sensor (VSS)

—19 —18 —17 —16 —15 —14 —13 —12 —11 —10 —9 —8 —7 —6 —5 —4 —3 —2 —1
 —37 —36 —35 —34 —33 —32 —31 —30 —29 —28 —27 —26 —25 —24 —23 —22 —21 —20
 —55 —54 —53 —52 —51 —50 —49 —48 —47 —46 —45 —44 —43 —42 —41 —40 —39 —38

A079113

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.



30416