

K263	AC compressor clutch cut-off relay
K143	AC compressor clutch relay
B138	Accelerator pedal position (APP) sensor
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y28	Exhaust gas recirculation (EGR) solenoid
A150	Fuel injection pump
Y132	Fuel injection timing solenoid
Y159	Fuel quantity adjuster
Y12	Fuel shut-off solenoid
B31	Fuel temperature sensor
F	Fuse
R5	Glow plug
A104	Glow plug control module
H25	Glow plug warning lamp
15	Ignition switch - ignition ON
50	Ignition switch - start signal
A162	Immobilizer control module
R95	Injection pump calibration resistor
B176	Injection pump cam ring position sensor
B175	Injection pump rotor position sensor
B141	Injector needle lift sensor
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
B83	Manifold absolute pressure (MAP) sensor
A171	Relay module
P7	Tachometer
B33	Vehicle speed sensor (VSS)

19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1
 37 36 35 34 33 32 31 30 29 28 27 26 25 24 23 22 21 20
 55 54 53 52 51 50 49 48 47 46 45 44 43 42 41 40 39 38

AD72618

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

