



K143	AC compressor clutch relay
S369	AC refrigerant quadruple pressure switch
B138	Accelerator pedal position (APP) sensor
31	Battery -
30	Battery +
S258	Clutch pedal position (CPP) switch
X1	Data link connector (DLC)
A35	Engine control module (ECM)
K46	Engine control relay
K12-I	Engine coolant blower motor relay 1
K12-II	Engine coolant blower motor relay 2
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
S358	Engine oil level switch
Y28	Exhaust gas recirculation (EGR) solenoid
B149	Exhaust gas recirculation (EGR) valve position sensor
F	Fuse
A104	Glow plug control module
H25	Glow plug warning lamp
R5	Glow plugs
15	Ignition switch - ignition ON
K258	Inertia fuel shut-off (IFS) relay
S39	Inertia fuel shut-off (IFS) switch
A150	Injection pump assembly
A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
S383	Intake manifold air actuator switch
Y179	Intake manifold air control actuator
A11	Multifunction control module
B33	Vehicle speed sensor (VSS)

A



B



AD23404

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

