



S341	AC refrigerant triple pressure switch
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
M6	Engine coolant blower motor
K12	Engine coolant blower motor relay
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y28	Exhaust gas recirculation (EGR) solenoid
A150	Fuel injection pump
B171	Fuel lever position sensor
Y12	Fuel shut-off solenoid
X28-I	Fuse box/relay plate, engine bay 1
R5	Glow plug
A104	Glow plug control module
H25	Glow plug warning lamp
Y131	Injection pump advance solenoid
B141	Injector needle lift sensor
A5	Instrument panel
A75	Instrumentation control module
Y66	Intake air flap control actuator
B25	Intake air temperature (IAT) sensor
B30	Mass air flow (MAF) sensor
A11	Multifunction control module
A171	Relay module (RM)
B33	Vehicle speed sensor (VSS)



bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

**NOTE:** In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.



39961