


A16	ABS control module
B161	AC refrigerant pressure sensor
B138	Accelerator pedal position (APP) sensor
B121	Barometric pressure (BARO) sensor
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
M6	Engine coolant blower motor
K12	Engine coolant blower motor relay
R46	Engine coolant blower motor resistor
R93	Engine coolant heater
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
B127	Exhaust gas pressure sensor
Y28	Exhaust gas recirculation (EGR) solenoid
B131	Exhaust gas temperature sensor
A242	Fuel additive control module
Y199	Fuel additive injector
M153	Fuel additive pump
S424	Fuel filler cap position switch
Y63	Fuel pressure regulator control solenoid
M12	Fuel pump
B26	Fuel system pressure sensor
B31	Fuel temperature sensor
F	Fuse
X28-II	Fuse box/relay plate, engine bay 1
X28-IV	Fuse box/relay plate, engine bay 2
X28-V	Fuse box/relay plate, engine bay 3
X28-I	Fuse box/relay plate, fascia 1
K93	Glow plug timer relay
H25	Glow plug warning lamp
R5	Glow plugs
S1	Ignition switch
X	Ignition switch - accessories
15	Ignition switch - ignition ON
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
Y84	Intake air valve control valve
Y102	Intake manifold air control solenoid
B83	Manifold absolute pressure (MAP) sensor
B30	Mass air flow (MAF) sensor
A11-I	Multifunction control module 1
A11-II	Multifunction control module 2

Y160	Piston cut-off solenoid
H50	Service indicator
X92	Shorting link connector
H111	Stop engine warning lamp
P7	Tachometer
A57	Transmission control module (TCM)
Y68	Turbocharger (TC) wastegate regulating valve
VAN	Vehicle area network (VAN)
P9	Vehicle speedometer



bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

**NOTE:** In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.