

|        |   |
|--------|---|
| A16    | ABS control module                                |
| B161   | AC refrigerant pressure sensor                    |
| B138   | Accelerator pedal position (APP) sensor           |
| 31     | Battery -   |
| 30     | Battery +   |
| S13    | Brake pedal position (BPP) switch                 |
| B132   | Camshaft position (CMP) sensor                    |
| S258   | Clutch pedal position (CPP) switch                |
| CAN-H  | Controller area network (data bus) high           |
| CAN-L  | Controller area network (data bus) low            |
| B54    | Crankshaft position (CKP) sensor                  |
| X1     | Data link connector (DLC)                         |
| A207   | Electronic stability program (ESP) control module |
| A35    | Engine control module (ECM)                       |
| M6     | Engine coolant blower motor                       |
| K12    | Engine coolant blower motor relay                 |
| K12-I  | Engine coolant blower motor relay 1               |
| K12-II | Engine coolant blower motor relay 2               |
| R46    | Engine coolant blower motor resistor              |
| K242   | Engine coolant heater relay                       |
| B24    | Engine coolant temperature (ECT) sensor           |
| H63    | Engine malfunction indicator lamp (MIL)           |
| Y28    | Exhaust gas recirculation (EGR) solenoid          |
| R64    | Fuel filter heater                                |
| Y194   | Fuel flow control valve                           |
| B186   | Fuel rail pressure (FRP) sensor                   |
| B31    | Fuel temperature sensor                           |
| B82    | Fuel/water separator sensor                       |
| F      | Fuse  |
| X28-II | Fuse box/relay plate, engine bay 1                |
| X28-I  | Fuse box/relay plate, fascia                      |
| H25    | Glow plug warning lamp                            |
| R5     | Glow plugs  |
| S1     | Ignition switch                                   |
| 15     | Ignition switch - ignition ON                     |
| Y3     | Injector  |
| A5     | Instrument panel                                  |
| A75    | Instrumentation control module                    |
| B25    | Intake air temperature (IAT) sensor               |
| B30    | Mass air flow (MAF) sensor                        |
| A11-I  | Multifunction control module 1                    |
| A11-II | Multifunction control module 2                    |
| P7     | Tachometer  |
| VAN    | Vehicle area network                              |
| B33    | Vehicle speed sensor (VSS)                        |
| P9     | Vehicle speedometer                               |

19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1  
 37 36 35 34 33 32 31 30 29 28 27 26 25 24 23 22 21 20  
 55 54 53 52 51 50 49 48 47 46 45 44 43 42 41 40 39 38

AD72618

|                   |                  |                          |              |
|-------------------|------------------|--------------------------|--------------|
| bl = blue         | br = brown       | el = cream               | ge = yellow  |
| gn = green        | gr = grey        | nf = neutral             | og = orange  |
| rs = pink         | rt = red         | sw = black               | vi = violet  |
| ws = white        | hbl = light blue | hgn = light green        | rbr = maroon |
| x = braided cable | y = high tension | z = non-cable connection |              |

**NOTE:** In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.



