

CRESCENDOSM

PRESENTED BY 
Gene Haas Foundation

2024 Field Manual

Case Packing: Case 23/24


FIM Offseason Edition!

v1.0

5.9.2.3 Packing Steps

1.


Case 23 and Case 24 are packed in similar fashion. The primary differences between the two are small parts at the end of the case pack, and the colored plastic components. This instruction set will show images of primarily the case 24 pack but explain packing case 23 as well.



SOLIDWORKS
Modeling Solutions Partner


2.

Place the Amp Frame at the end of the case as shown.



SOLIDWORKS
Modeling Solutions Partner

3. If you don't have all these parts right now, continue packing and slide them in the front of the Amp later





SOLIDWORKS
Modeling Solutions Partner

- 4.

Place the 5ft long truss sections into the base of the amp such that the truss fit into the designated spots in the amp gram.


They won't interfere,
no matter the orientation




Truss guides

SOLIDWORKS
Modeling Solutions Partner

5.




6.




From Amp connecting to Alliance Wall


10.




11.



13.



14.




15.

One box, can go
in either case





For Case 23, place the box
holding the 9 pieces of
chain from the stages on
top of the triangular truss.



SOLIDWORKS
Modeling Solutions Partner


16.

Cover the three pieces of 5ft truss with the light
and button box from the amp. Make sure that all
wires, lights, buttons, and other electrical
components have been put in case 7.



SOLIDWORKS
Modeling Solutions Partner



17.





There will be a gap here between the source weldment and truss sections because the stage weldments are packed in case 32.

In case 23 put the 4 remaining trap/microphone assemblies

In case 24 put the 6 stingray assemblies



18.



These two pieces from the source will lay on top of the truss sections. Have the larger black piece be first laying face up. Then lay the clear piece on top face down. Finally, put a strap around the whole roadcase, position the ratchet at the top of the case so it doesn't get in the way